



WARNING: Electrically disconnect mains AC supply before replacing fuse. Replacement fuse must be of equivalent size and type. Never insert fuse while branch circuit is energized.

CAUTION: The middle connection on the terminal block makes a mechanical connection to the chassis even with the ground wire removed.